

## How to Make a Spa Ozone-Ready and Install Ozonator

To make the spa ozone ready you must locate the 4 port manifold to the left of the spa pack.

On this manifold there will be two  $\frac{3}{4}$ " tubing lines coming off & two capped ports.

One  $\frac{3}{4}$ " tube goes to the waterfall control & the other goes to a 2" jet body in the footwell.

The one that goes to the 2" body is the one that ozone goes through.

You must trace the  $\frac{3}{4}$ " line to the body then trace the  $\frac{3}{8}$ " air line back to the upper left side air manifold or to wherever it goes & cut this line @ the manifold & cap the existing hole.

You must then reroute the  $\frac{3}{8}$ " line back to the front left corner & loop & tie to the frame.

This tube is attached to the valve which is attached to the tubing coming out of the ozone.

Mount ozone with two screws to frame & plug into pack @ slot labeled ozone (plug only goes in one way).