

## Changing modes on LED light

With spa running on low speed: press button once - light on - press again - jets high - press again - light off - press again - jets low - press again light on - etc. This must be done as fast as possible to go to the next color otherwise it locks in the last color. All other spas are on/off (light btn) to go to the next setting (must be done quickly or retains last color setting)